

## BAT LOUNGE CHAIR, HIGH BACK

Designed by GAMFRATESI

## GAMFRATESI CHAIR COLLECTION

### PRODUCT



### COLOURS (Legs)

#### Wood legs:

- Walnut



- Oak



- Oak black lacquered



#### Metal legs:

- Black powder coated



- Black chrome



- Brass



- Antique Brass



### DESCRIPTION



### FACTS

#### MEASUREMENT - L X W X H MM

Sitting height: 42cm

Seat width: 57 cm

Frame width: 85cm

Frame depth: 87 cm

Chair height: 101cm

#### WEIGHT ITEM

17 kg

#### PACKAGING TYPE

Cardboard box

#### PACKAGING MEASUREMENT - L X W X H CM

L:81 X W:89 X H: 105

#### WEIGHT PACKAGING - MATERIAL TYPE

- Delivery note: 5 g

- Cardboard box, FEFCO quality EB85BB: 2200 g

- Polybag PE: 200 g

- LD-EPE foam protector: 100 g

- Strapping: 10 g

#### WEIGHT PACKAGING

4 kg

#### WEIGHT - TOTAL

23,5 kg

#### NUMBER OF PARCELS

1 pcs.

#### FABRIC CONSUMPTION

Fabric consumption Seat and Back - 3,91M

Leather consumption - 6,49m<sup>2</sup>


### VERSIONS - FULLY UPHOLSTERED

#### CHAIR VERSIONS

**BAT LOUNGE CHAIR - Low Back**

**BAT LOUNGE CHAIR - High Back**

Order item - look for part number in the pricelist.



## ACCESSORIES

---

- Plastic glides are standard
- Possibility of leather upholstered armrest against added cost

## CLEANING AND MAINTENANCE

---

For cleaning the upholstered surface, first try to brush off the dirt gently. If this is not enough then vacuum the surface.

If further cleaning of the padding is needed, a stain remover is recommended. The cleaning has to be gentle and must always be tested on the most invisible area of the surface before the actual cleaning. Avoid blotches by gentle, circular rubbing towards the stain.

To avoid stains, quickly remove the dirt with a piece of absorbing household wipe and clean with water and colourless washing-up liquid.

Do not use the following products for the padding:

- Undiluted cleaning liquids.
- Bleach.
- Ammoniac.
- Soap for hard surfaces.

For dusting and light cleaning of the frame use a soft, dry cloth.

For further cleaning of the frame, use a soft cloth that is firmly wrung in clean water for gently wiping the surface, and then immediately use a dry cloth to wipe the surface again.

If more thorough cleaning is necessary, use a mild detergent or washing-up liquid dissolved in water on a firmly wrung cloth to wipe the seat. Afterwards, repeat the process with clean water as described above.

Polish with a soft cloth after wiping.

Do not use materials for maintenance that:

- Contain abrasive agents.
- Are basic, acidiferous or organic.

For the best maintenance of the product, protect it against sunlight and heat, and try to keep it away from moisture, grease and other dirt.

Furthermore, protect the surfaces against sharp objects and other that might scratch.

## TESTS.

---

FOAM:

Frontside of backrest foam: HR5050 – 15 mm - Fulfill requirements California Technical Bulletin 117

Backside of backrest foam: VB3842 – 5 mm

Seat foam CH4060 – 25 mm - Fulfill requirements BS5852 Crib 5 certificate